

DON'T USE CLEANER TISSUES FOR BONDING APPLICATIONS

A reliable bond does not start with the adhesive — it starts with proper surface preparation. Even the highest-quality adhesive cannot perform optimally if the surface is not completely dry, clean, and grease-free.

Why cleaner tissues create risks

In practice, ready-to-use cleaner tissues or wipes are often used for quick cleaning. Although convenient, they can create significant risks in professional bonding applications.

A tissue that is partially dried out or already contaminated cannot properly remove grease and dirt. In many cases, contamination is simply spread across the surface instead of being fully removed.

The consequences can be:

- reduced adhesion strength
- increased risk of bond failure
- unreliable long-term performance
- costly repairs and replacement

For structural or durable bonding applications, this is a risk that can easily be avoided.

The professional solution: TWEHA®Cleaner+

TWEHA® recommends the use of TWEHA®Cleaner+ for optimal surface preparation.

The correct method is simple:

1. Generously spray the surface to be bonded with TWEHA®Cleaner+
2. Wipe in one direction using clean paper or a lint-free cloth
3. Allow the surface to fully evaporate and dry

This ensures a surface that is truly:

- dry
- clean
- grease-free

— exactly what is required for maximum adhesion and long-term bonding performance.

Professional bonding starts with professional preparation

Successful bonding depends on controlling every detail.

By avoiding cleaner tissues, you eliminate the risk of invisible contamination and significantly improve the reliability of your bonding system.

Choose a controlled cleaning method with TWEHA®Cleaner+ — the professional foundation for durable adhesion.